



pulse50 quickstart guide



Before you charge

1 Make sure the unit is safe to use

To start charging

1 Place your access card or key fob on the reader; or open the bp pulse app.

2 Select the correct charging option for your electric vehicle (EV).

3 Connect your vehicle using the cable selected.

4 If you have selected the CHAdeMO cable, you will need to use the press-release button.

5 The unit will run a safety check and then start charging.

To finish charging

1 Place your access card or key fob on the reader; or press stop in the bp pulse app.

2 Remove the cable from your EV and place it back into the charging unit.

3 If your cable will not release, call our 24/7 customer support line. Do not press the emergency support button unless there is an emergency.

For assistance or further information please call 0330 016 5126 or visit www.bppulse.co.uk

